

IT'S EASY TO INSTALL REPLACEMENT WINDOWS HERE'S HOW

Installation of the Silver Line Window is a simple procedure. Look over these abbreviated instructions and you'll understand how the window has been designed to fit perfectly in place of the old window.

Installation is not complicated. The new window is basically a replacement for the track and operating sash of your old window. The frame remains intact, only the operating pieces are removed. In their place, the Silver Line Window is installed - built specifically for your opening.

1. Remove the Old Window



- Carefully remove the interior molding/stops and save for later use.
- Remove the cords and weights from side jambs so that the old wooden bottom sash may be easily removed.
- Remove the parting stops at the top and sides so that the old top sash can also be removed.
- If the existing window has preformed aluminum tracks, there will be no parting stops on the sides, only one on the top. Staples fastening the track to the opening should be removed. In this case, the sashes may be removed with the track.

2. Clean and Prepare the Opening



- Once the sashes and track are removed, clear the opening of any remaining debris. Fill any holes left by the sash track or the weights, pulleys, etc.
- Install the sill angle (included with our replacement windows) on the sill 1/8" behind the blindstop.
- Caulk the inside perimeter of the opening along the blindstop.
- Place the head expander (also included with purchase) onto the top of the window and apply a bead of caulk along the top. (You may wish to put insulation between the head expander and the window).

3. Set in the New Window



- Set window in opening, resting on sill angle and check for plumb and level. (If necessary, shim sides with flat shims to assure plumb and level. Also, shim behind screw holes so that tightening the mounting screws will not distort the frame).
- Once level, apply the installation screws (included with window) through the predrilled holes on the top and bottom of both side jambs until they are "finger tight". Once applied, tighten the jamb adjusters until they, too, are "finger tight".
- After screws have been applied, raise the head expander flush with the top of the opening and reapply the stops and moldings that were removed earlier.
- Apply a bead of caulk to where the molding meets the window to seal any gaps. Also apply caulk along outside of window to assure that any gaps have been filled/sealed.

